取扱説明書

保証書付き

裏表紙が保証書になっています。

HITACHI
Inspire the Next

家庭用

日立目もとケア

型式 MM-R01

（エム　エム　アール）

3時間充電式

お買い上げありがとうございます。
この「取扱説明書」をよくお読みになり正しくご使用ください。
お読みになった後は大切に保存してください。

もくじ

特長 …… 2
ご使用前の準備 …… 3
各部の名称と働き …… 6
安全上のご注意 …… 7
ご使用例 …… 11
使いかた …… 12
お手入れ …… 15
保存のしかた …… 15
「故障かな」と思ったときは …… 16
トラブルQ&A …… 17
お客様ご相談窓口 …… 18
保証とアフターサービス …… 19
仕様 …… 20
製品を廃棄するときのお願い …… 21

4902530086553

＜取扱説明書をお読みになるにあたって＞

●この取扱説明書については、将来予告なしに変更することがあります。
●製品改良のため、予告なく外観または仕様の一部を変更することがあります。

特　長

本製品は充電式の目もと専用のケア機器です。
●温モード
10 分間目もとをあたためます。
●冷モード
3 分間目もとをひやします。
●温 / 冷モード
10 分間の温モードの後、3分間の冷モードで目もとをリラックス＆リフレッシュします。
●「温」「温 / 冷」モードは、温度を「低・高」の 2 段階より選択できます。
●オートオフ機能
各モードが終了すると自動的に電源が切れます。
●ティシューを湿らせてご使用になりますと、目もとをじんわりリラックスできます。
●ティシューを湿らせずにご使用になりますと温熱がすぐに伝わり、すばやくかんたんリフレッシュできます。
●ずれ落ち防止のバンドがついています。

ご使用前の準備

つづく

●使いはじめの方、肌の敏感な方は毎日使用せず適度に間隔をあけてご使用ください。
●ティシューをリングで本体に取りつけてからご使用ください。
●使いはじめの温度設定は『低』からご使用ください。
●目薬をお使いの場合は、点眼後しばらくしてからご使用ください。
●目や目の周りが熱すぎると感じた場合は、すぐに使用を中止するか、「高」でご使用の場合は、「低」に切り替えてご使用ください。
●使用中は目を閉じ、くつろいで使用してください。
●つけまつげをお使いの場合は、はずしてご使用ください。
●メイクが落ちる場合があります。
●コンタクトレンズははずしてご使用ください。

充電のしかた

- 初めてご使用になる前に、充電してください。
- 電源は必ず交流100-240Vで、付属の電源アダプターをご使用ください。
- 充電推奨温度は10～35℃です。
  推奨温度を下回る温度では、充電反応が鈍くなり、十分に充電されずに使用回数が少なくなる場合があります。
- 蓄電池には寿命があります。
  (電池寿命は使用・保存状態により大きく変化します。)
  取扱説明書に従ってご使用頂いても、使用回数が極端に少なくなった場合は、電池の寿命が考えられます。

⚠警告	**ぬれた手で電源アダプターをコンセントに抜き差ししない。**（感電・ショートの原因）
	電源アダプターは浴室など水のかかるところや、湿気の多いところでは使用しない。（感電・ショートの原因）
⚠注意	**本体は水滴を十分にふき取り、乾燥させて充電する。**（感電・ショートの原因）

ご使用前の準備

■海外でのご使用について

- この商品は交流100-240V電源でAプラグのコンセントが使用できます。
- 同一国内でも地域により電圧およびプラグ形状が異なる場合がありますので、現地で十分お確かめください。

⚠注意	**使用前に必ずコンセントの電圧を確かめる。** (火災・感電の原因)
	交流240Vを超える電源で使用しない。 (火災・感電の原因)

・電圧およびプラグ形状については、現地のホテルや旅行社などにご相談ください。

■プラグアダプターの種類

・おもな種類(本品には付属していません。)

(mm)



・プラグアダプターは、使用される商品の消費電力に見合う容量のものをご使用ください。
・購入される場合は、空港などの免税店や現地のホテル・旅行社などにご相談ください。
・Aプラグ地域では、プラグアダプターなしで使用できます。



1 電源が切れていることを確認し、電源アダプターを本体とコンセントに接続します。



2 充電ランプが点灯していることを確認します。



- 充電時間は約３時間です。
- 電池残量により、充電時間が短くなることがあります。
- 充電が完了すると充電ランプが消灯します。
- １回の充電で約6回（１回約13分）使用可能ですが周囲環境温度によって使用回数は異なります。

※使用中に充電ランプが点滅したら充電してください。

3 充電ランプが消灯したことを確認し電源アダプターをコンセントと本体から抜きます。



本製品には、リチウムイオン電池を使用しています。
性能を十分に発揮させるために次のことを守ってください。

(1) 使用の都度充電しないでください。
電池の寿命が短くなります。

(2) 周囲温度が10～35℃未満で充電してください。
蓄電池の性質上、低温や高温では電池性能が低下する場合があります。

(3) 乾燥した涼しい所で保存してください。
40℃以上の暑い所や0℃以下の寒い所での保存は避けてください。

(4) 車中、船舶中などの家庭用以外での充電はしないでください。

各部の名称と働き



操作パネル



⑯ 電源アダプター

型式：K06S050100J



⑳ 付属品



安全上のご注意　必ずお守りください。　つづく

- ここに示した注意事項は、製品を安全に正しくお使いいただき、あなたや周囲の方への危害や損害を未然に防止するためのものです。
- 注意事項は次のように区分しています。
  いずれも安全に関する重要な内容ですので、必ず守ってください。

⚠危険	取り扱いを誤った場合、**使用者が死亡または重傷を負うことがあり、かつその切迫の度合いが高い危害の程度。**
⚠警告	取り扱いを誤った場合、**使用者が死亡または重傷を負うことが想定される危害の程度。**
⚠注意	取り扱いを誤った場合、**使用者が軽傷を負うことが想定されるか、または物的損害(家屋・家財など)の発生が想定される危害・損害の程度。**

＜絵表示の例＞

	記号は、**「禁止」(しないでください)**を示しています。 「分解禁止」　「水場での使用禁止」 「水ぬれ禁止」　「ぬれ手禁止」
	記号は、**「強制」(必ずしてください)**を示しています。 「一般的な行為」　「電源プラグをコンセントから抜く」

⚠警告

禁止

取扱説明書に記載されている以外の使い方はしない。
（事故やトラブル、故障の原因）

安全上のご注意　必ずお守りください。

⚠警告

禁止

次のような方は使用を避ける。（事故やトラブルの原因）
- ●顔面神経痛の人　●皮フ痛覚知覚障害のある人
- ●顔面の皮フの下に金属、プラスチック、シリコン等を埋め込んである人
- ●強度の近視の人（−6D以上）
  ご不明な場合は、医師にご確認いただくかコンタクトレンズのパッケージの記載をご確認ください。
- ●目の病気（白内障、緑内障、網膜剥離、眼底出血、飛蚊症など）のある人、またはあった人
- ●目の手術をおこなった人（レーシック手術直後はかかりつけの医師にご相談ください）
- ●有熱性疾患の人　●アレルギー体質の人
- ●皮フ病およびアトピー性皮フ炎の人　●敏感肌の人
- ●妊娠中の人（ホルモンバランスが不安定で肌トラブルの原因になります）
- ●ペースメーカー、人口内耳などの磁気障害の影響を受けやすい体内埋め込み型医療電気機器を使用している方、脳脊髄液短絡術用圧可変式シャントなどの磁気影響を受ける可能性のある医療電気機器を使用している方は、機器の誤作動の恐れががりますので使用しないでください。

下記の場合は使用しない。（事故やトラブルの原因）
- ●顔面に傷や湿疹、はれものなどがある場合
- ●顔面に皮フ炎、過度の日焼けなど、皮フに異常がある場合

交流100−240V以外の電源は使用しない。
（火災や感電の原因）

子どもには使わせない。また、幼児の手の届くところに置かない。（事故や故障の原因）

付属の電源アダプター以外は使用しない。また、付属の電源アダプターで他の商品を充電しない。
（感電、ショート、発火の原因）

コードが傷んだり、コンセントの差し込みがゆるいときは使用しない。（感電、ショート、発火の原因）

電源プラグや器具用プラグにピンやゴミを付着させない。（感電、ショート、発火の原因）

⚠警告

禁止	コードを傷つけたり、無理に曲げたり、引っ張ったり、ねじったり、たばねたり、重い物を載せたり、はさみ込んだり、加工したり電源アダプターなどに巻きつけたりしない。（コードが損傷し、火災や感電の原因）
水ぬれ禁止	水洗いは絶対にしない。 また水につけたり水をかけたりしない。 （故障やショートの原因）
ぬれ手禁止	ぬれた手で電源アダプターをコンセントに抜き差ししない。（故障やショートの原因）
水場での使用禁止	浴室など水のかかることろや湿気の多い所で使用したり充電や放置をしない。 （故障やショートの原因）
電源プラグを抜く	万一充電中に異常が発生したら、電源アダプターの電源プラグをコンセントからすぐ抜く。 （事故や火災の原因）
	お手入れの際は必ず電源アダプターを本体とコンセントから抜く。（感電、ショートの原因）
分解禁止	改造はしない。また、修理技術者以外の人が修理をしない。（火災・感電・けが・故障の原因）
必ず守る	使用中痛みや不調を感じたときや、使用後肌に異常を感じたときは、使用を中止して専門医に相談する。 （肌トラブルなどの原因）
	本体に異音や異常が発生したら直ちに使用を停止し、電源アダプターと共に、販売店へ相談する。 （事故やトラブルの原因）
	電源プラグや器具用プラグにほこりが付着しないように定期的に掃除する。（感電、ショート、発火の原因）

安全上のご注意　必ずお守りください。

⚠注意

禁止	**本体を装着中、他の作業はしない。** （思わぬ事故の原因）
	使用前に、温感部にキズや変形がないか確認する。 （肌を傷つける原因）
	肌に傷や炎症がある場合は絶対に使用しない。 （肌トラブルや痛みの原因）
	落としたり、強い衝撃を与えたりしない。 （けが・故障の原因）
必ず守る	**電源プラグや器具用プラグを抜くときは、コードを持たずに抜く。**（断線・感電・ショート・発火の原因）
	マスカラは落として使用する。 （目を傷つけたり、炎症の原因）
	つけまつげは必ずはずす。 （目を傷つけたり、炎症の原因）
	まつげ用エクステをつけた人は使用しない。 （目を傷つけたり、炎症の原因）
	コンタクトレンズは必ずはずす。 （目を傷つけたり、炎症の原因）
	使用の際は必ずティシューを取りつけ、使用毎に必ずティシューを交換する。 （肌トラブルや炎症の原因）
	使用中は装着したまま寝ない。 （目を傷つけたり、炎症の原因）
	目もと以外に使用しない。 （肌を傷つける原因）
電源プラグを抜く	**充電時以外は、必ず電源アダプターをコンセントから抜く。** （劣化による感電や火災の原因）

ご使用例

ティシューの取りつけについて



- ご使用の際は必ずティシューを取りつけてください。
- ティシューを取りつける前に温感部にキズや変形がないか確認してください。
- ティシューは湿らせずにそのままお使いいただけます。
- ティシューの種類によっては水に湿らせると溶けたり、破れたりする場合があります。
  水溶性ではないティシューをご使用ください。
- ティシューはたてに4つ折りにしてリングで本体に取りつけてください。
- ご使用後は必ずティシューをはずし、本体を清潔に保ってください。

使いかた

ご使用の際は、電源プラグと器具用プラグは抜いてください。
本体と電源アダプターがつながった状態では作動しません。

- 使用推奨温度は15℃～35℃です。温感部の温度は使用環境温度により変わることがあります。

1 カップに水を注ぎます。

カップの右図の位置まで水道水を注ぎます。

- ティシューを固定した状態で蛇口から水をかけないようにしてください。

2 ティシューを固定します。

温感部に4つ折りにしたティシューを乗せ、付属のリングで固定します。
リングの中央をしっかりと押して、外れないことを確認してください。リングは磁石で本体とくっつきます。



3 ティシューを湿らせます。

ティシューをカップに用意した水で湿らせます。
カップの水は両目分ですので、片目ずつ湿らせてください。



4 電源ボタンを押し電源を入れます。

電源を入れると毎回温度は「低」、モードは「温/冷」からスタートします。

5 モード切替ボタンを押し、モードを選択します。

モードを切り替えたい場合はモード切替ボタンを押してください。



※モードを途中で切り替えた場合、動作時間が合計で13分間になった時点で自動停止します。
※「冷」モードに切り替えた場合は「冷」モード累計約3分で停止となります。

保護機能

連続で3回ご使用になると保護機能が働き電源が入らない場合があります。
15分以上おいてから電源を入れてください。



電源を入れると温度表示ランプとモード表示ランプが5回点滅

6 温度切替ボタンを押し、温度を選択します。

途中で温度を「低」から「高」にしたい場合は温度ボタンを押して「高」にしてください。



温感部の温度：　高　約40℃
低　約38℃
冷　約20℃
（周囲環境温度が25℃のとき）

7 本体を装着します。

目を閉じて、温感部を目の周りにそってあててください。

使いかた

座って使用する場合

●バンドで固定する

バンドの取りつけかた

バンドの取りつけ金具を本体の取りつけフックにかけます。



8 オートオフ機能が働いたときは自動停止します。

モード途中で電源を切りたい場合は電源ボタンを押してください。
モード表示ランプと温度表示ランプが消灯するのを確認してください。

オートオフ機能

「温/冷」モード：13分
「温」モード：10分
「冷」モード：3分

9 ティシューをはずします。

本体からリングを外し、ティシューを廃棄します。
ご使用毎に必ず新しいティシューへ交換してください。

- 必ず表示内容を確認してから、装着してしてください。
  途中でモードを切り替える場合は、目から機器をはずしてモード切り替えをおこなってください。
- 熱すぎると感じた場合は、すぐに使用を中止してください。
- 使い始めは1回を週2～3日、使用約1か月後からは1日1回の使用が目安です。
  連続でのご使用は、眼精トラブル、肌トラブルを起こす原因となりますのでおやめください。

お手入れ

- 本体やリングについた汚れはティシューなどでふき取ります。
- 汚れが落ちにくいときは、水を含ませて固く絞った布でふき取ります。

⚠警告	本体は水洗いしない。または水につけたり、水をかけたりしない。（故障の原因）
⚠注意	ベンジン、シンナー、アルコールなどでふいたりしない。（変形、変色の原因）

保存のしかた

- 本体は湿気やほこりの少ない所に保存します。

注意

直射日光の当たるところ（夏期の自動車内など）、熱器具の近くや高温な場所に放置しない。（変形、変色の原因）

⚠警告	水のかかるところや浴室など湿気の多いところに放置しない。（故障の原因）
	コードは電源アダプターや本体に巻きつけない。（コードが破損する原因）

「故障かな」と思ったときは

エラー表示

ランプ表示	処　置
「低」点滅（橙）	本体内部の保護機能が働いて異常停止しています。 電源ボタンを押す。繰り返し起こる場合は販売店またはお客様ご相談窓口へご相談ください。
 「温」点滅（緑）	
「冷」点滅（緑）	

修理を依頼される前に、次のことをお調べください。

症 状	点検するところ	直しかた
電源ボタンを押しても温感部が温かくならない。	本体と電源アダプターとコンセントがつながれていませんか？	本体から電源アダプターを取りはずしてください。
	充電切れになっていませんか？	充電してからお使いください。
	充電しているときには使用できません。	本体から電源アダプターを取りはずしてください。
電源アダプターが非常に熱い。	コンセントの差し込みがゆるくありませんか？	ゆるくないコンセントを使用してください。
使用中に停止する。	充電切れになっていませんか？	充電してからお使いください。
	「温/冷」モードでは約13分、「温」モードでは約10分、「冷」モードでは約3分で自動停止します。 異常ではありません。	

症 状	点検するところ	直しかた
電源が入らない。	連続で3回ご使用になると保護機能が働きます。 15分以上おいてから電源ボタンを入れてください。	
「温/冷」モード、「冷」モードオートオフ後に温感部が温かくなる。	製品の特性上、「温/冷」モード、「冷」モードご使用後温感部が温かくなります。 異常ではありません。	

以上のことをお調べになり、それでも異常があるときは、ご自分で修理なさらないで、お買い上げの販売店にご相談ください。

トラブルQ&A

Q1.水の代わりにティシューに化粧水を含ませて使用してもよいか。

- 化粧水の使用は目にしみたり、異常をきたす原因となりますので、絶対におやめください。

Q2.温感部が温かく（または冷たく）ならない。

- 温感部の表面温度と周囲温度の差がなくなり温度を感じない場合があります。
  使用推奨周囲温度でご使用ください。(15℃～35℃)

Q3.ティシューの種類は何を使用してもよいか。

- ティシューの種類によっては水に湿らせると溶けたり、破れたりする場合があります。
  水溶性ではないティシューをご使用ください。

お客様ご相談窓口

日立家電品についてのご相談や修理はお買い上げの販売店へ
なお、転居されたり、贈物でいただいたものの修理などで、ご不明な点は下記窓口にご相談ください。
※下記窓口の内容は、予告なく変更させていただく場合がございます。

ホームページに「よくあるご質問」について掲載しておりますので、ご活用ください。
http://kadenfan.hitachi.co.jp/q_a/index.html

商品情報やお取り扱いについてのご相談はお客様相談センターへ

TEL 0120-3121-11
FAX 0120-3121-34

(受付時間) 9:00～17:30(月～土)
9:00～17:00(日･祝日)

年末年始は休ませていただきます。
携帯電話、PHSからもご利用できます。

修理に関するご相談はエコーセンターへ

TEL 0120-3121-68
FAX 0120-3121-87

(受付時間) 9:00～19:00(月～土)
9:00～17:30(日･祝日)

携帯電話、PHSからもご利用できます。

- 「持込修理」および「部品購入」については、上記サービス窓口にて各地区のサービスセンターをご紹介させていただきます。
- ご相談、ご依頼いただいた内容によっては弊社のグループ会社に個人情報を提供し対応させていただくことがあります。
- 修理のご依頼をいただいたお客様へ、アフターサービスに関するアンケートハガキを送付させていただくことがあります。

保証とアフターサービス（必ずお読みください。）

この商品の保証とアフターサービスについては、日本国内においてのみ適用します。

保証書（一体）

● **この商品は保証書つきです。**
保証書は、必ず「お買い上げ日」・「販売店名」などの記入をお確かめのうえ、販売店から受け取っていただき、内容をよくお読みの後、大切に保存してください。

保証期間	お買い上げの日から1年間

修理を依頼されるときは　持込修理

16～17ページの『「故障かな」と思ったときは』を調べていただき、なお異常のあるときは、使用を中止し、必ずお買い上げの販売店にご相談ください。

■ **保証期間中は**
修理に際しましては、保証書をご提示ください。
保証書の記載内容に基づいて修理させていただきます。

■ **保証期間が過ぎているときは**
修理によって機能が維持できる場合は、ご希望により有料で修理させていただきます。

■ **修理料金のしくみ**（修理料金＝技術料+部品代）

技術料	診断、部品交換、調整、修理完了時の点検などの作業にかかる費用です。技術者の人件費、技術教育費、測定機器などの設備費、一般管理費などが含まれます。
部品代	修理に使用した部品代金です。その他修理に付帯する部材等を含む場合があります。

補修用性能部品の保有期間

● 当社は、この目もとケアの補修用性能部品を製造打ち切り後5年間保有しています。

● 補修用性能部品とは、その商品の機能を維持するために必要な部品です。

ご不明な点や修理に関するご相談は

● 修理に関するご相談並びにご不明な点は、お買い上げの販売店または18ページのお客様ご相談窓口にお問い合わせください。

仕様

定格電圧	AC100-240V　50-60Hz共用
入力容量	0.3A　（電源アダプター：K06S050100J）
消費電力	約9W以下（充電時）
使用電池	リチウムイオン電池　DC3.7V、1620mAh　1本
充電時間	3時間（室温10～35℃）
定格時間	最大13分間
質量	本体　：約235g 電源アダプター：約65g
付属品	バンド、カップ

愛情点検

長年ご使用の目もとケアの点検を！

こんな症状はありませんか

- 電源アダプターが異常に熱くなる。
- 本体が変形していたり、こげくさい臭いがする。
- その他の異常・故障がある。

お願い

故障や事故防止のため、電源を切り、電源プラグをコンセントから抜いて、必ず販売店またはお客様ご相談窓口にご相談ください。

製品を廃棄するときのお願い

つづく

⚠危険	**取り出した蓄電池は充電や以下のことをしない。** (発熱・発火・破裂の原因) ● 火への投入、過熱をしない。 ● くぎで刺したり、衝撃を与えたり、分解・改造をしない。 ● ⊕と⊖を金属などで接触させない。 ● ネックレス、ヘアピンなどと一緒に持ち運んだり保管しない。 ● 火のそばや炎天下など高温の場所で放置しない。
⚠警告	**取り出した蓄電池は乳幼児の手の届くところに置かない。**万一、飲み込んだと思われるときは、すぐに医師に相談する。
	蓄電池の液が漏れたときは、素手で触れずに以下の処置をする。 ● 液が目に入ったときは、目をこすらずに、すぐにきれいな水で洗ったあと医師に相談する。 ● 液が体や衣服に付いたときは、きれいな水で十分洗い流したあと医師に相談する。
	製品を廃棄するとき以外は分解しない。 (火災・感電・けがの原因)

■ **この製品には、リチウムイオン電池を使用しております。リチウムイオン電池はリサイクル可能な貴重な資源です。ご使用済み製品の廃棄に際しては、リチウムイオン電池を取りはずしていただき、製品のお買い求めのお店、または、リチウムイオン電池のリサイクル協力店へお持ちいただき、リサイクルへご協力をお願いいたします。**

Li-ion00
リチウムイオン電池はリサイクルへ

リサイクル協力店の詳細は、一般社団法人JBRCのホームページをご参照ください。
http://www.jbrc.com

■ **蓄電池以外にも、リサイクル可能な部品が含まれています。蓄電池以外の部品の廃棄に際しましては、お住いの地域の条例などに従って処理してください。**

製品を廃棄するときのお願い

リチウムイオン電池を廃棄する目的以外で製品の分解は行なわないでください。
性能および安全性が損なわれ、故障や事故の原因となります。

リチウムイオン電池の取りはずしかた

1 充電残量がある場合は、完全に動かなくなるまで、電源を入れてリチウムイオン電池を放電させる。

2 バックカバーのネジ(7本)を⊕ドライバーではずし、取りつけフックをひっぱって、フロントカバーをはずす。





3 キバンのネジ(3本)を⊕ドライバーではずし、キバンをはずす。



4 バッテリーカバーのネジ(2本)を⊕ドライバーではずし、バッテリーカバーをはずす



5 リチウムイオン電池を取り出し、キバンからコネクターを抜く。



販売元：日立コンシューマ・マーケティング株式会社 リビングサプライ社
〒162-0814　東京都新宿区新小川町6-29　アクロポリス東京

製造元：日立マクセル株式会社
〒822-1296　福岡県田川郡福智町伊方4680

Product warranty and after-sales service are only valid in Japan.

Preparation before use (P.3～5)

- If using the device for the first time or for users who have sensitive skin, use the device at appropriate intervals, not every day.
- Place a tissue on the main body with a ring.
- Start the device from the temperature setting “Low.”
- If you use eye drops, use the device only after waiting an appropriate time.
- If you feel your eyes or the surrounding areas begin to become hot, immediately stop using the device, or switch to “Low” if it operates at “High.”
- Close your eyes and relax during use.
- Remove false eyelashes before using the device.
- Makeup may be removed.
- Remove contact lenses before using the device.

How to charge (P.3)

- Charge before first use.
- Make sure to use the included power adaptor for 100 - 240V AC power.
- The recommended charging temperature is in the range of 10 – 35°C
  At a temperature below the recommended temperature, the charging response may slow down, causing an insufficient charge and a reduced number of operating times.
- Each battery has a service life.
  (The battery life greatly varies according to the conditions of use and storage.)
  If the number of operating times is extremely small in spite of use in accordance with the instructions, it is considered that the battery life is about to expire.

⚠WARNING

Never connect or disconnect to/from the outlet with wet hands.
(Cause of electric shocks and short circuits)
Do not use the power adaptor in a place where water is splashed, such as a bathroom, or in a place with high humidity. (Cause of electric shocks and short circuits)

⚠CAUTION

Wipe away water drops on the main body sufficiently to dry it before charging.
(Cause of electric shocks and short circuits)

1 Confirm that the power turns off, and connect the power adaptor to the main body and electric outlet.
2 Confirm that the charge lamp lights up.
- The charging time is approximately 3 hours.
- The charging time may be shortened according to the remaining battery level.
- When charging is completed, the charge lamp turns off.
- One charge lasts for approximately six times of use (approximately 13 minutes/use), however, the number of use times depends on the ambient environment temperature.
- When the charge lamp flashes during operation, recharge the battery.

3 Confirm that the charge lamp turns off, and remove the power adaptor from the electric outlet and the main body.

Names of parts and their functions (P.6)

① Front cover
② Operation panel
③ Back cover
④ Battery : Lithium ion battery 1
⑤ Mounting hook
⑥ Thermal sensing part
⑦ Magnet
⑧ Ring
⑨ Body socket
⑩ Charge lamp (Red)
⑪ Temperature indication lamp (Orange)
⑫ Temperature selector button
⑬ Power button
⑭ Mode selector button
⑮ Mode indication lamp (Green)
⑯ Power adaptor : Model: K06S050100J
⑰ Power plug
Insert into an outlet all the way.
⑱ Plug for device
⑲ Cord
⑳ Accessories
㉑ Band
㉒ Size adjusting bracket
㉓ Mounting bracket
㉔ Cup
㉕ Main body

Safety precautions (P.7～10)

- Precautions described here are intended for safe and correct use of this product and are to prevent injury and damage to you and others before they occur.
- Precautions are classified as follows.
  Make sure to observe the precautions because they are related to safety and important details.

⚠DANGER	Indicates that improper handling may result in death or serious injury to a user, and the extent of hazard that its urgency is high.
⚠WARNING	Indicates the extent of hazard that improper handling is predicted to result in death or serious injury to a user.
⚠CAUTION	Indicates the extent of hazard or damage that improper handling is predicted to result in slight injury to a user or damage to property (house, household effects, etc.).

<Example of pictorial indication>

	The ⃠ symbol indicates "Prohibited" (Do not do this). "Disassembly prohibited" "Use prohibited in wet areas" "Prohibited from being made wet" "Prohibited from use with wet hands"
	The ● symbol indicates "Compulsory" (Make sure to do this). "General action" "Pull out the power cord from outlet"

⚠WARNING

Never use this product by other methods which are not described in this instruction manual. (Cause of accidents, trouble and failure)
The following persons should avoid using the device. (Cause of accidents or trouble)
- Persons with facial paralysis
- Persons with cutaneous pain perceptual disorder
- Persons with metal, plastic, silicon etc., embedded under facial skin.
- Persons who are highly near-sighted (-6D or worse)

If you are not sure, check the description on the contact lens package or consult your doctor.
- Persons who have or have had an eye disease (such as a cataract, glaucoma, retinal detachment, fundal hemorrhage or eye floater)
- Persons who have had eye surgery (consult your doctor if you recently had LASIK surgery.)
- Persons with a febrile disease
- Persons with a predisposition to allergies
- Persons with a skin disease or atopic dermatitis
- Persons who have sensitive skin
- Persons who are pregnant (hormone imbalance may cause skin trouble.)
- Persons who use an implanted electro-medical apparatus such as a pacemaker or cochlear implant that is susceptible to magnetic interference or an electro-medical apparatus such as a pressure variable shunt for a cerebrospinal fluid shunt that may be susceptible to magnetic influence should not use the device because it may cause malfunction of the apparatus.

Do not use in the following cases. (Cause of accidents or trouble)
- There is a wound, rash, or skin boil on the face
- There is a skin abnormality such as irritation or excessive sunburn on the face

Use only 100-240V AC for power supply. (Cause of fires and electric shocks)
Do not allow children to use this product. Also, do not place within close reach of infants. (Cause of accidents or failure)
Never use any other power adaptor than the ones included.
Also, do not charge any other product with the included power adaptor.
(Cause of electric shocks, short circuits and ignition)

Never use a cord if they are damaged or insertion to the outlet is loosened.
(Cause of electric shocks, short circuits and ignition)
Never allow pins or dust to adhere to the power plug and plug for device.
(Cause of electric shock, short circuit and ignition)
Do not damage, unnecessarily bend, pull, twist, bind, place a heavy object on top, sandwich, process or wind the cord around the power adapter, etc.
(If the cord breaks, fires or electric shocks may occur.)

Never wash with water. Also, never soak them in water or splash water on them.
(Cause of electric shocks and short circuits)

Make sure to disconnect the power cord from the outlet for maintenance.
Never connect or disconnect the power plug to/from the outlet with wet hands.
(Cause of electric shocks and short-circuits)

Never use, charge or leave in a place where water is splashed such as the bathroom or in a place with high humidity. (Cause of failures and short-circuits)

If any abnormality occurs during charge or use, immediately pull out the power plug of the power adaptor from the outlet. (Cause of accident or fire)
For maintenance, make sure to remove the power plug from the outlet.
(Cause of electric shocks or injury)

Never modify the shaver. Only a qualified technician may make repairs.
(Cause of fires, electric shocks, injuries and failures)

When feeling pain or disorder during use of this product, and sensing anything wrong with your skin after use, stop using and consult a dermatologist.
(Cause of skin trouble etc.)
If any unusual sound or abnormality occurs on the main body, immediately stop using and contact the distributor together with the power adaptor.
(Cause of accidents and trouble)
Regularly clean the power plug and plug for device so that dust does not form on them. (Cause of electric shocks, short circuits or ignition)

⚠CAUTION

Do not perform other operations while wearing the main body.
(Cause of unexpected accidents)
Confirm there is no damage or deformity on the thermal sensing part before use.
(Cause of damage on skin)
Never use this product if there is some injury or wound to the skin.
(Cause of skin trouble or pain)

Do not drop this product, or give a strong impact. (Cause of injury or failure)

Pull out the power plug and plug for device without holding the cord.
(Cause of breakage, electric shock, short-circuit and ignition)
Wipe eyelash liners.
(Cause of damage or irritation to eyes)
Make sure to remove false eyelashes.
(Cause of damage or irritation to eyes)
Persons who wear eyelash extensions should not use the device.
(Cause of damage or irritation to eyes)
Make sure to remove contact lenses.
(Cause of damage or irritation to eyes)
When using the device, make sure to place a tissue and replace it for each time of use.
(Cause of skin trouble or eye irritation)
Do not wear the device while sleeping.
(Cause of damage or irritation to eyes)
Use the device only for eyes.
(Cause of damage to skin)

Make sure to remove the power adaptor from the outlet when the battery is not being charged. (Cause of electric shock or fire due to deterioration)

Example for use (P.11)

Installation of the tissue

- When using the device, make sure to place a tissue.
- Before placing a tissue, confirm there is no damage or deformity on the thermal sensing part.
- Tissues can be used without being moistened.
- Some types of tissues may dissolve or tear when moistened.
- Use a tissue not soluble in water.
- Fold the tissue vertically into four and place it on the main body with the ring.
  After use, make sure to remove the tissue and keep it clean.

How to use (P.12～14)

Remove the power plug and plug for the device.
The device does not operate while the main body and the power adaptor are connected.

- The recommended temperature for operation is 15°C to 35°C. The temperature of the thermal sensing part may change depending on the operating environment temperature.

1 Pour water into the cup.
Pour tap water up to the level of the cup shown at the right.
- Do not scatter water from the tap with the tissue fixed.

2 Fix the tissue.
Place the tissue folded into four on the thermal sensing part and fix it with the attached ring. Securely press the center of the ring to confirm that it will not slip off. The ring is attracted to the main body by the magnet.

3 Moisten the tissue.
Moisten the tissue with water prepared in the cup.
The water in the cup is for both eyes. Moisten each eye with the tissue.

4 Press the power button to turn on power.
When the power is turned on, the temperature starts at “Low” and the mode starts at “Hot/Cool.”

5 Press the mode selector button to select a mode.
When you switch the mode, press the mode selector button.
- When the mode is switched in the middle of operation, the operation stops automatically
- when the operation time reaches 13 minutes in total.
- When the mode is switched to “Cool,” the operation stops when the total time in “Cool” mode continues for approximately 3 minutes.

Protective function
When each mode is continuously used for three times, a protective function starts and the power may not turn on. Leave the device for 15 minutes or more and turn on the power.

6 Press the temperature selector button to select the temperature.
When you switch the temperature from “Low” to “High,” press the temperature button to switch to “High.”

Temperature of thermal sensing part:	
High	Approximately 40°C
Low	Approximately 38°C
Cool	Approximately 20°C

(When ambient environment temperature is 25°C)

7 Wear the main body.
Close your eyes and slowly place the thermal sensing part around your eyes.
When sitting
- Secure the main body with a band.

How to mount the band Attach a band mounting bracket onto a mounting hook of the main body.

8 When an Auto Off function works, the operation is automatically stopped.
When you want to turn off the power in the middle of a mode, press the power button.
Confirm that the mode indication lamp and the temperature indication lamp turn off.

Auto Off function “Hot/Cool” mode: 13 minutes “Hot” mode: 10 minutes “Cool” mode: 3 minutes

9 Remove the tissue.
Remove the ring from the main body, and dispose of the tissue.
Make sure to replace with a new tissue for each time of use.

- Make sure to confirm the description before wearing the device.
  When switching the mode in the middle of the operation, remove the device and switch the mode.
- If you feel excessive hotness, immediately stop using the device.
- As a guide, use the device two or three days per week for first-time use, and once a day for approximately one month after use.
  Do not use the device continuously because it may cause eye irritation or skin trouble.

Care for main body (P.15)

- Wipe off the cosmetic on the ring and the body with a tissue.
- When dirt is difficult to remove, wipe it off with a cloth after saturating it with water and wring it thoroughly.

⚠WARNING	Never wash with water. Also, never soak them in water or splash water on them. (Cause of electric shocks and short circuits)
⚠CAUTION	Do not use alcohol, benzene or thinner. (Cause of deformation or discoloration)

How to preserve (P.15)

- Store the main body in a place with little humidity and dust.

Cautions
Do not leave in an area subject to direct sunlight (inside of a vehicle in summer, etc.) or near heaters. (Cause of deformation or discoloration)

⚠WARNING	Do not leave in a water splashing area or an area with significant humidity, such as a bath. (Cause of short-circuits or failure)
	Do not wind the cord around the power adaptor or the main body. (Cause of cord breakage)

MEMO

MEMO

MEMO

日立目もとケア保証書

持込修理

保証期間内に取扱説明書などの注意書きにしたがった正常なご使用状態で故障した場合には、本書記載内容にもとづきお買い上げの販売店が無料修理いたします。
お買い上げの日から下記の期間内に故障した場合には、商品と本書をお持ちいただき、お買い上げの販売店に修理をご依頼ください。

型式		MM-R01	保証期間	本体：1年
※お買い上げ日		平成　　年　　月　　日		
※お客様	お名前	様		
	ご住所	〒 電話　　（　　）		
※販売店	住所 店名	〒 電話　　（　　）		

※印欄に記入のない場合は無効となりますから必ずご確認ください。

1. 保証期間内でも次のような場合には有料修理となります。
   (イ) 使用上の誤り、または改造や不当な修理による故障または損傷。
   (ロ) お買い上げ後の落下、引っ越し、輸送などによる故障または損傷。
   (ハ) 火災、地震、水害、落雷、その他の天災地変、公害や異常電圧による故障または損傷。
   (ニ) 車両、船舶にとう載して使用された場合に生じた故障または損傷。
   (ホ) 業務用など一般家庭以外で使用されて生じた故障または損傷。
   (ヘ) 本書のご提示がない場合。
   (ト) 本書にお買い上げ年月日、お客様名、販売店名の記入のない場合あるいは字句を書き換えられた場合。
2. この商品は持込修理の対象商品です。郵送などで修理依頼された場合の送料などはお客様の負担となります。また、出張修理をご希望の場合には、出張に要する実費を申し受けます。
3. ご転居の場合は事前にお買い上げの販売店にご相談ください。
4. 贈答品などで本書に記入してあるお買い上げの販売店に修理をご依頼になれない場合には、取扱説明書に記載の「お客様ご相談窓口」にご相談ください。
5. 本書は再発行いたしませんので紛失しないよう大切に保存してください。
6. 本書は日本国内においてのみ有効です。Effective only in Japan

- この保証書は本書に明示した期間、条件のもとにおいて無料修理をお約束するものです。したがってこの保証書によって保証書を発行している者(保証責任者)、およびそれ以外の事業者に対するお客様の法律上の権利を制限するものではありませんので、保証期間経過後の修理などについてご不明の場合は、お買い上げの販売店または取扱説明書に記載の「お客様ご相談窓口」にお問い合わせください。
- お客様にご記入いただいた保証書の写しは、保証期間内のサービス活動およびその後の安全点検活動のために記載内容を利用させて頂く場合がございますので、ご了承ください。
- 保証期間経過後の修理、補修用性能部品の保有期間について詳しくは、取扱説明書をご覧ください。

修理メモ

日立コンシューマ・マーケティング株式会社　リビングサプライ社
〒162-0814　東京都新宿区新小川町6-29 アクロポリス東京
電話 お客様相談センター 0120-3121-11